

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763



Modelo : VGP-BPL2

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

Fabricante : SONY

Bateria Compatível c/ os seguintes modelos:

Sony

- Vaio PCG-6C1M, PCG-6C1N, PCG-6C2L, PCG-6E1M, PCG-6N2M, PCG-6P1L, PCG-6P1P, PCG-6P2L, PCG-6P2P, PCG-6R1M, PCG-791M, PCG-792L, PCG-7A1M, PCG-7D1M, PCG-7G1M, PCG-7H2M, PCG-7K1L, PCG-7M1M, PCG-7N1M, PCG-7N2M, PCG-7R1M, PCG-7T1M, PCG-7T2M, PCG-7V1M, PCG-7V2M, PCG-7Y1M, PCG-CP1L, PCG-FS93G

- Vaio VFB-S1 Series: VFB-S1-XP

- Vaio VFN-S9 Series: VFN-S90PSY5

- Vaio VGC-LA Series: VGC-LA38C, VGC-LA38C/S, VGC-LA38G, VGC-LA38T

- Vaio VGC-LB Series: VGC-LB51, VGC-LB51B, VGC-LB52B, VGC-LB52HB, VGC-LB53B, VGC-LB53HB, VGC-LB61B/P, VGC-LB62B/P, VGC-LB62B/W, VGC-LB63B/L, VGC-LB63B/P, VGC-LB63B/W, VGC-LB91S, VGC-LB92HS, VGC-LB92S, VGC-LB93HS, VGC-LB93S

- Vaio VGN-91 Series: VGN-91PS

- Vaio VGN-AR Series: VGN-AR1, VGN-AR11, VGN-AR11S, VGN-AR130G, VGN-AR150G, VGN-AR170, VGN-AR170GU1, VGN-AR170PU2, VGN-AR18CP, VGN-AR18GP, VGN-AR18TP, VGN-AR190G, VGN-AR2, VGN-AR21, VGN-AR21B, VGN-AR21M, VGN-AR21MR, VGN-AR21S, VGN-AR21SR, VGN-AR230, VGN-AR230G, VGN-AR250, VGN-AR250G, VGN-AR25GP, VGN-AR270, VGN-AR270G, VGN-AR270GA, VGN-AR270P, VGN-AR28GP, VGN-AR290, VGN-AR290FG, VGN-AR290G, VGN-AR21, VGN-AR21B, VGN-AR21M, VGN-AR21S, VGN-AR230G, VGN-AR250G, VGN-AR25GP, VGN-AR270, VGN-AR28GP, VGN-AR290FG, VGN-AR290G, VGN-AR3, VGN-AR31E, VGN-AR31M, VGN-AR31MR, VGN-AR31S, VGN-AR31SR, VGN-AR320, VGN-AR320E, VGN-AR350E, VGN-AR370, VGN-AR370E, VGN-AR38C, VGN-AR38G, VGN-AR390, VGN-AR390CE, VGN-AR390E, VGN-AR390FG, VGN-AR31E, VGN-AR31M, VGN-AR31S, VGN-AR320E, VGN-AR370, VGN-AR38C, VGN-AR38G, VGN-AR390E, VGN-AR390FG, VGN-AR5, VGN-AR50B, VGN-AR51DB, VGN-AR52DB, VGN-AR590E, VGN-AR70B, VGN-AR71DB, VGN-AR72DB, VGN-AR80PS, VGN-AR80S, VGN-AR810, VGN-AR810E, VGN-AR81PS, VGN-AR81S, VGN-AR820, VGN-AR820E, VGN-AR825, VGN-AR825E, VGN-AR82PS, VGN-AR82S, VGN-AR82US, VGN-AR840, VGN-AR840E, VGN-AR90PS, VGN-AR90S, VGN-AR91PS, VGN-AR91S, VGN-AR92PS, VGN-AR92S, VGN-AR92US

- Vaio VGN-C1 Series: VGN-C1, VGN-C1/G, VGN-C1/P, VGN-C1/W, VGN-C11C, VGN-C11C/B, VGN-C11C/G, VGN-C11C/H, VGN-C11C/P, VGN-C11C/W, VGN-C12C,

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

VGN-C12C/B, VGN-C12C/W, VGN-C12GP/W,
VGN-C12GPW, VGN-C13G/H, VGN-C140G, VGN-C140G/ B,
VGN-C140QG/B, VGN-C150P, VGN-C150P/B,
VGN-C15GP/B, VGN-C15GPB, VGN-C15TP/ B,
VGN-C15TP/ W, VGN-C15TP/B, VGN-C15TP/W, VGN-C190,
VGN-C190CP/ G, VGN-C190CP/ H, VGN-C190CP/ P,
VGN-C190CP/G, VGN-C190CP/H, VGN-C190CP/P,
VGN-C190G, VGN-C190P, VGN-C190P/ H, VGN-C190P/H,
VGN-C190PB, VGN-C190PG, VGN-C190PH, VGN-C190PP,
VGN-C190PW, VGN-C1S/G, VGN-C1S/H, VGN-C1S/P,
VGN-C1S/W, VGN-C1Z/B

- Vaio VGN-C2 Series: VGN-C200, VGN-C210E,
VGN-C210E/H, VGN-C210E/P, VGN-C21C/H, VGN-C21CH,
VGN-C21GH/W, VGN-C21GHW, VGN-C220E,
VGN-C220E/H, VGN-C22CH, VGN-C22GH/B,
VGN-C22GH/W, VGN-C240E, VGN-C240E/B, VGN-C240EB,
VGN-C240QE/B, VGN-C240QEB, VGN-C250N,
VGN-C250N/B, VGN-C25G, VGN-C25G/B, VGN-C25G/G,
VGN-C25G/H, VGN-C25G/L, VGN-C25G/P, VGN-C25G/W,
VGN-C25GB, VGN-C25T/G, VGN-C25T/H, VGN-C25T/W,
VGN-C260E, VGN-C270CE, VGN-C270CE/G,
VGN-C270CE/L, VGN-C270CE/P, VGN-C270CEG,
VGN-C270CEL, VGN-C270CEP, VGN-C270CN,
VGN-C270CN/H, VGN-C270CNH, VGN-C290, VGN-C290E,
VGN-C290NW, VGN-C291, VGN-C291NW,
VGN-C291NW/G, VGN-C291NW/H, VGN-C2S, VGN-C2S/G,
VGN-C2S/H, VGN-C2S/L, VGN-C2S/P, VGN-C2S/W,
VGN-C2Z, VGN-C2Z/B

- Vaio VGN-C3 Series: VGN-C31GH/W, VGN-C31GHW

- Vaio VGN-C5 Series: VGN-C50HA/W, VGN-C50HB/W,
VGN-C51, VGN-C51HA/W, VGN-C51HB/W

- Vaio VGN-C6 Series: VGN-C60HB/G, VGN-C60HB/H,
VGN-C60HB/L, VGN-C60HB/P, VGN-C61, VGN-C61/G,
VGN-C61/H, VGN-C61G, VGN-C61H, VGN-C61HB/G,
VGN-C61HB/H, VGN-C61HB/L, VGN-C61HB/P, VGN-C61L

- Vaio VGN-C7 Series: VGN-C70B/W, VGN-C71B/W

- Vaio VGN-C9 Series: VGN-C90, VGN-C90HS,
VGN-C90NS, VGN-C90S

- Vaio VGN-FE Series: VGN-FE11H, VGN-FE11H.CEK,
VGN-FE11M.G4, VGN-FE11S, VGN-FE11S.CEK,
VGN-FE11S.G4, VGN-FE15C, VGN-FE18C, VGN-FE18GP,
VGN-FE20, VGN-FE21, VGN-FE21/W, VGN-FE25CP,
VGN-FE25GP, VGN-FE25TP, VGN-FE28, VGN-FE28CP,
VGN-FE28GP, VGN-FE30B, VGN-FE31, VGN-FE31B/ W,
VGN-FE31B/W, VGN-FE31M, VGN-FE31Z, VGN-FE32B/W,
VGN-FE32H/W, VGN-FE32HA/W, VGN-FE32HB/W,
VGN-FE33, VGN-FE33B/W, VGN-FE33H/W,
VGN-FE33HB/W, VGN-FE35C, VGN-FE35GP,
VGN-FE35TP, VGN-FE38CP, VGN-FE38GP, VGN-FE41M,
VGN-FE45G/W, VGN-FE45T/W, VGN-FE48C,
VGN-FE48G/H, VGN-FE48M, VGN-FE50B, VGN-FE51B/ H,
VGN-FE51B/H, VGN-FE52B/H, VGN-FE53, VGN-FE53B/W,
VGN-FE53HB/W, VGN-FE550, VGN-FE550FM,
VGN-FE550G, VGN-FE570, VGN-FE570G, VGN-FE590,
VGN-FE590GC, VGN-FE590P03, VGN-FE590PA,

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

VGN-FE590PB, VGN-FE630, VGN-FE630Q, VGN-FE650G,
VGN-FE660G, VGN-FE670G, VGN-FE680G, VGN-FE690,
VGN-FE690GB, VGN-FE690PB, VGN-FE770G, VGN-FE790,
VGN-FE790GN, VGN-FE790PL, VGN-FE870E/H,
VGN-FE870QE, VGN-FE880E/H, VGN-FE890,
VGN-FE890EB, VGN-FE890EG, VGN-FE890ER,
VGN-FE890N/H, VGN-FE90PS, VGN-FE90S, VGN-FE91PS,
VGN-FE91S, VGN-FE92, VGN-FE92HS, VGN-FE92NS,
VGN-FE92S, VGN-FE, VGN-FE11H, VGN-FE11H.CEK,
VGN-FE11M.G4, VGN-FE11S, VGN-FE11S.CEK,
VGN-FE11S.G4, VGN-FE15C, VGN-FE18C, VGN-FE18GP,
VGN-FE20, VGN-FE21, VGN-FE21/W, VGN-FE25CP,
VGN-FE25GP, VGN-FE25TP, VGN-FE28, VGN-FE28CP,
VGN-FE28GP, VGN-FE30B, VGN-FE31, VGN-FE31B/W,
VGN-FE31M, VGN-FE31Z, VGN-FE32B/W, VGN-FE32H/W,
VGN-FE32HA/W, VGN-FE32HB/W, VGN-FE33,
VGN-FE33B/W, VGN-FE33H/W, VGN-FE33HB/W,
VGN-FE35C, VGN-FE35GP, VGN-FE35TP, VGN-FE38CP,
VGN-FE38GP, VGN-FE45G/W, VGN-FE45T/W, VGN-FE48C,
VGN-FE48G/H, VGN-FE48M, VGN-FE50B, VGN-FE51B/H,
VGN-FE52B/H, VGN-FE53, VGN-FE53B/W,
VGN-FE53HB/W, VGN-FE550G, VGN-FE570G, VGN-FE590,
VGN-FE590GC, VGN-FE590P03, VGN-FE590PA,
VGN-FE590PB, VGN-FE630, VGN-FE630Q, VGN-FE650G,
VGN-FE660G, VGN-FE670G, VGN-FE680G, VGN-FE690,
VGN-FE690GB, VGN-FE690PB, VGN-FE770G, VGN-FE790,
VGN-FE790GN, VGN-FE790PL, VGN-FE870E/H,
VGN-FE870QE, VGN-FE880E/H, VGN-FE890,
VGN-FE890N/H, VGN-FE90PS, VGN-FE90S, VGN-FE91PS,
VGN-FE91S, VGN-FE92, VGN-FE92HS, VGN-FE92NS,
VGN-FE92S,

• Vaio VGN-FJ Series: VGN-FJ10B, VGN-FJ11/W,
VGN-FJ11B/ W, VGN-FJ11B/W, VGN-FJ12/W, VGN-FJ12B/
W, VGN-FJ12B/W, VGN-FJ150, VGN-FJ150/W,
VGN-FJ150F, VGN-FJ150W, VGN-FJ170, VGN-FJ170/ B,
VGN-FJ170/B, VGN-FJ170B, VGN-FJ170P, VGN-FJ170P/ B,
VGN-FJ170P/B, VGN-FJ170PB, VGN-FJ170Q,
VGN-FJ170Q/B, VGN-FJ180, VGN-FJ180P, VGN-FJ180P/ G,
VGN-FJ180P/ L, VGN-FJ180P/ R, VGN-FJ180P/ W,
VGN-FJ180P/G, VGN-FJ180P/L, VGN-FJ180P/R,
VGN-FJ180P/W, VGN-FJ180PB, VGN-FJ1S, VGN-FJ1S/L,
VGN-FJ1S/W, VGN-FJ1Z/W, VGN-FJ21B/ G, VGN-FJ21B/ L,
VGN-FJ21B/ R, VGN-FJ21B/G, VGN-FJ21B/L,
VGN-FJ21B/R, VGN-FJ22B/ G, VGN-FJ22B/ L, VGN-FJ22B/
R, VGN-FJ22B/G, VGN-FJ22B/L, VGN-FJ22B/R,
VGN-FJ230, VGN-FJ230F, VGN-FJ240, VGN-FJ240FP,
VGN-FJ250, VGN-FJ250F, VGN-FJ250P, VGN-FJ250P/B,
VGN-FJ260, VGN-FJ260FP, VGN-FJ270, VGN-FJ270/B,
VGN-FJ270B, VGN-FJ270P, VGN-FJ270P/ B, VGN-FJ270P/
BK1, VGN-FJ270P/B, VGN-FJ270P/BK1, VGN-FJ270Q,
VGN-FJ290, VGN-FJ290L1B, VGN-FJ290L1G,
VGN-FJ290L1L, VGN-FJ290L1R, VGN-FJ290L1W,
VGN-FJ290P, VGN-FJ290P1/ G, VGN-FJ290P1/ GK1,
VGN-FJ290P1/ L, VGN-FJ290P1/ LK1, VGN-FJ290P1/ R,
VGN-FJ290P1/ RK1, VGN-FJ290P1/ V, VGN-FJ290P1/ W,

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

VGN-FJ290P1/ WK1, VGN-FJ290P1/B, VGN-FJ290P1/G,
VGN-FJ290P1/GK1, VGN-FJ290P1/L, VGN-FJ290P1/LK1,
VGN-FJ290P1/R, VGN-FJ290P1/RK1, VGN-FJ290P1/V,
VGN-FJ290P1/W, VGN-FJ290P1/WK1, VGN-FJ2S/W,
VGN-FJ330F, VGN-FJ340, VGN-FJ340FP, VGN-FJ370,
VGN-FJ370/BC, VGN-FJ370B, VGN-FJ370P,
VGN-FJ370P/BC, VGN-FJ3M/W, VGN-FJ3S/W, VGN-FJ56C,
VGN-FJ56GP, VGN-FJ57, VGN-FJ57C, VGN-FJ57GP,
VGN-FJ57SP, VGN-FJ58C, VGN-FJ58GP, VGN-FJ58SP,
VGN-FJ65L/W, VGN-FJ66C, VGN-FJ66GP/ W,
VGN-FJ66GP/W, VGN-FJ67C, VGN-FJ67GP/ W,
VGN-FJ67GP/W, VGN-FJ68C, VGN-FJ68GP/ W,
VGN-FJ68GP/W, VGN-FJ68GPW, VGN-FJ76GP/ W,
VGN-FJ76GP/W, VGN-FJ77, VGN-FJ77C, VGN-FJ78,
VGN-FJ78C, VGN-FJ78GP/ B, VGN-FJ78GP/B,
VGN-FJ79TP/ V, VGN-FJ79TP/ W, VGN-FJ79TP/V,
VGN-FJ79TP/W, VGN-FJ90PS, VGN-FJ90PS1,
VGN-FJ90PS2, VGN-FJ90S, VGN-FJ91PS, VGN-FJ91S,
VGN-FJ92PS, VGN-FJ92S, VGN-FJ, VGN-FJ10B,
VGN-FJ11/W, VGN-FJ11B/W, VGN-FJ12/W, VGN-FJ12B/W,
VGN-FJ170/B, VGN-FJ170P/B, VGN-FJ180P/G,
VGN-FJ180P/L, VGN-FJ180P/R, VGN-FJ180P/W,
VGN-FJ21B/G, VGN-FJ21B/L, VGN-FJ21B/R, VGN-FJ22B/G,
VGN-FJ22B/L, VGN-FJ22B/R, VGN-FJ270P/B,
VGN-FJ270P/BK1, VGN-FJ290, VGN-FJ290L1B,
VGN-FJ290L1G, VGN-FJ290L1L, VGN-FJ290L1R,
VGN-FJ290L1W, VGN-FJ290P1/G, VGN-FJ290P1/GK1,
VGN-FJ290P1/L, VGN-FJ290P1/LK1, VGN-FJ290P1/R,
VGN-FJ290P1/RK1, VGN-FJ290P1/V, VGN-FJ290P1/W,
VGN-FJ290P1/WK1, VGN-FJ370B, VGN-FJ3M/W,
VGN-FJ3S/W, VGN-FJ56C, VGN-FJ56GP, VGN-FJ57C,
VGN-FJ57GP, VGN-FJ58C, VGN-FJ58GP, VGN-FJ66C,
VGN-FJ66GP/W, VGN-FJ67C, VGN-FJ67GP/W,
VGN-FJ68C, VGN-FJ68GP/W, VGN-FJ76GP/W,
VGN-FJ77C, VGN-FJ78C, VGN-FJ78GP/B, VGN-FJ79TP/V,
VGN-FJ79TP/W, VGN-FJ90PS, VGN-FJ90S, VGN-FJ91PS,
VGN-FJ91S, VGN-FJ92PS, VGN-FJ92S

• Vaio VGN-FS Series: VGN-FS115, VGN-FS115B,
VGN-FS115E, VGN-FS115M, VGN-FS115MR, VGN-FS115S,
VGN-FS115Z, VGN-FS115ZR, VGN-FS15C, VGN-FS15GP,
VGN-FS15LP, VGN-FS15SP, VGN-FS15TP, VGN-FS18CP,
VGN-FS18GP, VGN-FS18LP, VGN-FS18SP, VGN-FS18TP,
VGN-FS195VP, VGN-FS195XP, VGN-FS20, VGN-FS21,
VGN-FS215B, VGN-FS215E, VGN-FS215F, VGN-FS215M,
VGN-FS215MR, VGN-FS215S, VGN-FS215x, VGN-FS215Z,
VGN-FS21B, VGN-FS22B, VGN-FS22VB, VGN-FS23B,
VGN-FS25C, VGN-FS25GP, VGN-FS25SP, VGN-FS285B,
VGN-FS285E, VGN-FS285H, VGN-FS285M, VGN-FS285x,
VGN-FS28C, VGN-FS28GP, VGN-FS28SP, VGN-FS295VP,
VGN-FS295XP, VGN-FS30B, VGN-FS315B, VGN-FS315E,
VGN-FS315H, VGN-FS315M, VGN-FS315MR, VGN-FS315S,
VGN-FS315SR, VGN-FS315Z, VGN-FS31B, VGN-FS32B,
VGN-FS33B, VGN-FS35C, VGN-FS35GP, VGN-FS35SP,
VGN-FS35TP, VGN-FS38C, VGN-FS38GP, VGN-FS38SP,
VGN-FS395VP, VGN-FS3B, VGN-FS415B, VGN-FS415E,

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

VGN-FS415M, VGN-FS415S, VGN-FS415W, VGN-FS43,
VGN-FS485B, VGN-FS48C, VGN-FS48GP, VGN-FS48GP/B,
VGN-FS500, VGN-FS500 CTO, VGN-FS500B, VGN-FS500B
CTO, VGN-FS500P, VGN-FS500P CTO, VGN-FS500P12,
VGN-FS50B, VGN-FS515, VGN-FS515B, VGN-FS515E,
VGN-FS515H, VGN-FS51B, VGN-FS520, VGN-FS520B,
VGN-FS52B, VGN-FS530, VGN-FS530B, VGN-FS53B,
VGN-FS540, VGN-FS540P, VGN-FS550, VGN-FS550F,
VGN-FS550KIT1, VGN-FS550P, VGN-FS570, VGN-FS610,
VGN-FS610FP, VGN-FS615, VGN-FS615F, VGN-FS620,
VGN-FS620/W, VGN-FS620P, VGN-FS620PW, VGN-FS625,
VGN-FS625B, VGN-FS625B/ W, VGN-FS625B/W,
VGN-FS625BW, VGN-FS630, VGN-FS630/ W,
VGN-FS630/W, VGN-FS630F, VGN-FS630W, VGN-FS635,
VGN-FS635B, VGN-FS635B/ W, VGN-FS635B/W,
VGN-FS635BW, VGN-FS640, VGN-FS640/ W,
VGN-FS640/W, VGN-FS640FP, VGN-FS640Q,
VGN-FS640QW, VGN-FS640W, VGN-FS645, VGN-FS645P,
VGN-FS645P/ H, VGN-FS645P/H, VGN-FS645PH,
VGN-FS650, VGN-FS650F, VGN-FS655, VGN-FS655FP,
VGN-FS660, VGN-FS660/ W, VGN-FS660/W, VGN-FS660P,
VGN-FS660P/W, VGN-FS660PW, VGN-FS660W,
VGN-FS670, VGN-FS670FG, VGN-FS675, VGN-FS675P,
VGN-FS675P/ H, VGN-FS675P/H, VGN-FS675PH,
VGN-FS680, VGN-FS680/ W, VGN-FS680/W, VGN-FS680W,
VGN-FS690, VGN-FS690 CTO, VGN-FS690B, VGN-FS690B
CTO, VGN-FS690P, VGN-FS690P CTO, VGN-FS70B,
VGN-FS710, VGN-FS710/W, VGN-FS710FP, VGN-FS710W,
VGN-FS715, VGN-FS715F, VGN-FS715P/W, VGN-FS715W,
VGN-FS71B, VGN-FS720, VGN-FS720W, VGN-FS730,
VGN-FS730/W, VGN-FS730F, VGN-FS730W, VGN-FS740,
VGN-FS740/ W, VGN-FS740/W, VGN-FS740FP,
VGN-FS740Q, VGN-FS740QW, VGN-FS740W, VGN-FS742,
VGN-FS742/ W, VGN-FS742/W, VGN-FS742W,
VGN-FS745P, VGN-FS745P/ H, VGN-FS745P/H,
VGN-FS745PH, VGN-FS750, VGN-FS750F, VGN-FS750P,
VGN-FS750P/ W, VGN-FS750P/W, VGN-FS750PW,
VGN-FS750W, VGN-FS755, VGN-FS755FP,
VGN-FS755P/H, VGN-FS760, VGN-FS760/W, VGN-FS760Q,
VGN-FS760QW, VGN-FS760W, VGN-FS770,
VGN-FS770/W, VGN-FS770FG, VGN-FS770W, VGN-FS775,
VGN-FS775P, VGN-FS775P/ H, VGN-FS775P/H,
VGN-FS775PH, VGN-FS780, VGN-FS780/ W,
VGN-FS780/W, VGN-FS780W, VGN-FS790, VGN-FS790
CTO, VGN-FS7901, VGN-FS7902, VGN-FS790B,
VGN-FS790B CTO, VGN-FS790BA/BZ, VGN-FS790BH,
VGN-FS790P, VGN-FS790P-CTO, VGN-FS800, VGN-FS810,
VGN-FS810/W, VGN-FS810FP, VGN-FS810W, VGN-FS812,
VGN-FS812F, VGN-FS815, VGN-FS815F, VGN-FS830,
VGN-FS830/W, VGN-FS830Q, VGN-FS830W, VGN-FS840,
VGN-FS840/ W, VGN-FS840/W, VGN-FS840W, VGN-FS850,
VGN-FS850P, VGN-FS850P/W, VGN-FS850PW,
VGN-FS850Q, VGN-FS850W, VGN-FS875, VGN-FS875P,
VGN-FS875P/ H, VGN-FS875P/H, VGN-FS875P/HK1,
VGN-FS875PH, VGN-FS890, VGN-FS8900, VGN-FS8900M,

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

VGN-FS8900P, VGN-FS8900P3, VGN-FS8900P3K1,
VGN-FS8900P4, VGN-FS8900P5, VGN-FS8900P5K1,
VGN-FS8900V, VGN-FS90PS, VGN-FS90S, VGN-FS91PS,
VGN-FS91PSY, VGN-FS91S, VGN-FS920, VGN-FS92PS,
VGN-FS92PS1, VGN-FS92PS2, VGN-FS92PS3,
VGN-FS92PS6, VGN-FS92S, VGN-FS930, VGN-FS930F,
VGN-FS93G, VGN-FS940, VGN-FS950, VGN-FS960,
VGN-FS960P, VGN-FS965, VGN-FS965F, VGN-FS970,
VGN-FS970P, VGN-FS980, VGN-FS980F, VGN-FS980Q,
VGN-FS985, VGN-FS985FP, VGN-FS990, VGN-FS,
VGN-FS115B, VGN-FS115M, VGN-FS115S, VGN-FS115Z,
VGN-FS15C, VGN-FS15GP, VGN-FS15SP, VGN-FS15TP,
VGN-FS18CP, VGN-FS18GP, VGN-FS18SP, VGN-FS18TP,
VGN-FS195VP, VGN-FS21, VGN-FS215B, VGN-FS215E,
VGN-FS215M, VGN-FS215S, VGN-FS215Z, VGN-FS21B,
VGN-FS22B, VGN-FS22VB, VGN-FS23B, VGN-FS25C,
VGN-FS25GP, VGN-FS25SP, VGN-FS285B, VGN-FS285E,
VGN-FS285H, VGN-FS285M, VGN-FS28C, VGN-FS28GP,
VGN-FS28SP, VGN-FS30B, VGN-FS315B, VGN-FS315E,
VGN-FS315H, VGN-FS315M, VGN-FS315S, VGN-FS315Z,
VGN-FS31B, VGN-FS32B, VGN-FS33B, VGN-FS35C,
VGN-FS35GP, VGN-FS35TP, VGN-FS38C, VGN-FS38GP,
VGN-FS415E, VGN-FS415M, VGN-FS415S, VGN-FS43,
VGN-FS48C, VGN-FS48GP, VGN-FS500, VGN-FS500P12,
VGN-FS50B, VGN-FS515, VGN-FS51B, VGN-FS520B,
VGN-FS52B, VGN-FS530B, VGN-FS53B, VGN-FS540P,
VGN-FS550, VGN-FS570, VGN-FS625B/W, VGN-FS630/W,
VGN-FS635B/W, VGN-FS640/W, VGN-FS640QW,
VGN-FS645P/H, VGN-FS660/W, VGN-FS675P/H,
VGN-FS680/W, VGN-FS690, VGN-FS70B, VGN-FS71B,
VGN-FS740/W, VGN-FS742/W, VGN-FS745P/H,
VGN-FS750P/W, VGN-FS775P/H, VGN-FS780/W,
VGN-FS790, VGN-FS7901, VGN-FS7902, VGN-FS840/W,
VGN-FS875P/H, VGN-FS875P/HK1, VGN-FS8900,
VGN-FS8900M, VGN-FS8900P3, VGN-FS8900P3K1,
VGN-FS8900P4, VGN-FS8900P5, VGN-FS8900P5K1,
VGN-FS8900V, VGN-FS91PS, VGN-FS91PSY, VGN-FS91S,
VGN-FS92PS, VGN-FS92PS1, VGN-FS92PS2,
VGN-FS92PS3, VGN-FS92PS6, VGN-FS92S, VGN-FS980,
VGN-FS990

- Vaio VGN-FT Series: VGN-FT31B, VGN-FT32B,
VGN-FT50B, VGN-FT51B, VGN-FT52B, VGN-FT52DB,
VGN-FT53DB, VGN-FT73DB, VGN-FT90PS, VGN-FT90S,
VGN-FT91PS, VGN-FT91S, VGN-FT92PS, VGN-FT92S,
VGN-FT93S

- Vaio VGN-FZ Series: VGN-FZ19VN, VGN-K30,
VGN-K50B

- Vaio VGN-N1 Series: VGN-N11H/W, VGN-N11M/W,
VGN-N11S/W, VGN-N130G/W, VGN-N130G/WK1,
VGN-N130P/B, VGN-N150G/W, VGN-N150G/WK1,
VGN-N150P/B, VGN-N150P/BK1, VGN-N170G/T,
VGN-N170G/TK1, VGN-N170G/W, VGN-N170G/WK1,
VGN-N17C, VGN-N17C/B, VGN-N17C/W, VGN-N17G,
VGN-N19VP/B

- Vaio VGN-N2 Series: VGN-N21E/W, VGN-N21M/W,

Hardware > PEÇAS PARA PORTATEIS > Baterias para portateis > BATERIA SONY VAIO VGN-AR11 6900mAh PRETA

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

VGN-N21S/W, VGN-N21Z/W, VGN-N230E/B, VGN-N230E/T,
VGN-N230E/W, VGN-N230N/B, VGN-N250EW,
VGN-N250N/B, VGN-N250QEW, VGN-N270E/T,
VGN-N270E/W, VGN-N270EW, VGN-N27GH,
VGN-N27GH/B, VGN-N29VN/B

- Vaio VGN-N3 Series: VGN-N31M/W, VGN-N31S/W,
VGN-N31Z/W, VGN-N320E/B, VGN-N320E/W,
VGN-N350E/B, VGN-N350E/T, VGN-N350E/W,
VGN-N37GH/B, VGN-N37GHB, VGN-N385E/W,
VGN-N38E/W, VGN-N38M/W, VGN-N38Z/W, VGN-N50HB,
VGN-N51B, VGN-N51HB, VGN-N395E, VGN-N395E/B,
VGN-N395E/W, VGN-N395EB

- Vaio VGN-S1 Series: VGN-S150, VGN-S150/P,
VGN-S150F, VGN-S150KIT1, VGN-S150P, VGN-S16C,
VGN-S16GP

Volts: 11.1V

Cel.: Li-Ion 9 Cel.

mAh: 6900mAh

Cor: Preto

Tipo: Compatível

Garantia: 1 Ano

Dimensões: 204*60*19mm

Peso: 450g

(não é uma lista completa).

Se não encontra o que procura ou tem dúvidas,
contacte-nos.

Preço: €60,95IVA Incluído (€49,55 Sem IVA)

Hardware > PEÇAS PARA PORTATEIS > Baterias para portateis > BATERIA SONY VAIO VGN-AR11 6900mAh PRETA

BATERIA SONY VAIO VGN-AR11 6900mAh PRETA PID01763

Disponível desde: Este produto foi adicionado ao nosso catalogo em:Domingo 22 Novembro, 2009

NCB