

BATERIA Packard Bell EasyNote LS11 AS10D75 7800mAh PID06862



Modelo : AS10D75

BATERIA Packard Bell EasyNote LS11 AS10D75 7800mAh PID06862

Fabricante : Acer

Bateria Compatível c/ os seguintes modelos:

ACER

- Aspire 4250, 4250G, 4250Z
- Aspire 4251, 4251G, 4251Z
- Aspire 4252, 4252G, 4252Z
- Aspire 4253, 4253G, 4253Z
- Aspire 4333, 4333Z, 4339, 4339Z, 4349, 4349Z, 4350, 4350G, 4352, 4352G
- Aspire 4551, 4551G, 4551G-P322G32Mn, 4551 P, 4552, 4552-5078, 4552G, 4552Z, 4560, 4560G
- Aspire 4625, 4625G
- Aspire 4733, 4733G, 4733Z, 4733ZG
- Aspire 4738, 4738G, 4738Z, 4738ZG
- Aspire 4739, 4739G, 4739Z, 4739ZG
- Aspire 4741, 4741G, 4741G-332G32Mnsk, 4741G-332G50Mn, 4741G-372G50Mnkk02, 4741G-372G50Mnkk06, 4741G-432G50Mnkk01, 4741G-5452G50Mnkk04, 4741G-5462G50Mnkk05, 4741G-5464G50Mn, 4741T, 4741TG, 4741Z, 4741ZG, 4741ZG-P602G50Mnkkc, 4741ZG-P622G50Mnkk03,
- Aspire 4743, 4743G, 4743Z, 4743ZG
- Aspire 4750, 4750G, 4750Z, 4750ZG
- Aspire 4755, 4755G, 4755T, 4755Z, 4755ZG
- Aspire 4771, 4771G, 4771Z
- Aspire 5250, 5250G
- Aspire 5251, 5251-1005, 5251-1549, 5251G
- Aspire 5252, 5252G, 5252ZG
- Aspire 5253, 5253G
- Aspire 5333, 5333G
- Aspire 5336, 5336G, 5336T, 5336G
- Aspire 5551, 5551-2013, 5551-2036, 5551-2805, 5551-4200, 5551-4937, 5551-P323G32Mnsk, 5551G, 5551G-4280, 5551G-4591, 5551G-P324G32Mn
- Aspire 5552, 5552G, 5552TG, 5552Z, 5552ZG
- Aspire 5560, 5560G, 5560 T, 5560Z, 5560ZG, 5560 V3
- Aspire 5733, 5733G, 5733Z
- Aspire 5736, 5736G, 5736Z, 5736ZG
- Aspire 5741, 5741-332G25Mn, 5741-333G32Mn, 5741-334G32Mn, 5741-334G50Mn, 5741-3404, 5741-3541, 5741-433G32Mn, 5741-434G50Mn, 5741-5698, 5741-5763, 5741G, 5741G-332G50Mn, 5741G-333G32Bn, 5741G-334G50Mn, 5741G-334G64Mn, 5741G-434G64Bn, 5741G-5452G50Mnck, 5741G-5452G50Mnkk, 5741G-5452G50Mnsk, 5741TG, 5741Z, 5741ZG
- Aspire 5742, 5742G, 5742TG, 5742Z, 5742ZG

BATERIA Packard Bell EasyNote LS11 AS10D75 7800mAh PID06862

- Aspire 5750, 5750G, 5750G-2312G50, 5750TG, 5750Z, 5750ZG
- Aspire 5755, 5755G, 5755Z, 5755ZG
- AS5741, AS5741-H32C/S, AS5741-H32C/SF, AS5741-H54D/LS, AS5741-H54D/S, AS5741-H54D/SF, AS5741-N32C/KF, AS5741-N32D/K, AS5741-N54E/K, AS5741-N54E/KF
- Aspire 7251
- Aspire 7551, 7551-2755, 7551-3068, 7551-3416, 7551-3634, 7551-5358, 7551G, 7551G-5407, 7551G-5821, 7551G-6477, 7551Z, 7551ZG
- Aspire 7552G, 7552G-5107, 7552G-5488, 7552G-6061, 7552Z
- Aspire 7560, 7560G
- Aspire 7741, 7741-333G25Mn, 7741-5137, 7741-7870, 7741G, 7741G-333G25Bn, 7741G-333G32Mn, 7741G-334G50Mn, 7741G-3647, 7741G-374G64Mn, 7741G-434G50Mn, 7741G-464G64Mn, 7741G-7017, 7741TG, 7741Z, 7741Z-4475, 7741Z-4592, 7741Z-4633, 7741Z-4643, 7741Z-4815, 7741Z-5731, 7741ZG, 7741ZG-P604G50Mn, 7741Z-P614G50Mn, 7741ZG
- Aspire 7750, 7750G, 7750Z, 7750ZG
- Aspire E1 Series: E1-421, E1-431, E1-431G, E1-471, E1-471G, E1-521, E1-531, E1-531G, E1-571, E1-571G
- Aspire V3 Series: V3-531, V3-531G, V3-551, V3-551G, V3-571, V3-571G, V3-731, V3-731G, V3-771, V3-771G
- TravelMate 4350
- TravelMate 4370, 4370G
- TravelMate 4740, 4740-352G32Mn, 4740-432G50Mna, 4740-5261, 4740-5452G50Mnssb, 4740-5462G50Mnss02, 4740-7552, 4740-7787, 4740G, 4740T, 4740TG, 4740Z, 4740ZG
- TravelMate 4750, 4750G, 4750TG, 4750Z, 4750ZG,
- TravelMate 5335, 5335G, 5335Z, 5335ZG
- TravelMate 5340, 5340G
- 5344,
- 5360, TM5360G
- TravelMate 5542, 5542G, 5542Z, 5542ZG
- TravelMate 5735, 5735G, 5735Z, 5735ZG,
- TravelMate 5740, 5740-332G16Mn, 5740-332G25Mn, 5740-333G25Mn, 5740-333G32Mn, 5740-352G25Mn, 5740-372G25Mnss, 5740-434G32Mn, 5740-5092, 5740-524G32Mn, 5740-5896, 5740-5952, 5740-6070, 5740-6291, 5740-6529, 5740G, 5740G-334G32Mn, 5740G-434G32Mn, 5740G-524G50Mn, 5740G-528G64Mn, 5740G-5452G32Mnss, 5740G-6765, 5740TG, 5740Z, 5740Z-P602G25Mn, 5740Z-P604G32Mnss, 5740ZG
- TravelMate 5742, 5742-372G25Mn, 5742-373G32Mn, 5742-463G32Mn, 5742-5562G50Mnss01, 5742-7013, 5742-7159, 5742-7399, 5742-7906, 5742-7908, 5742G, 5742TG, 5742Z, 5742Z-4693, 5742ZG
- TravelMate 5744, 5744G, 5744Z
- TravelMate 5760, 5760G, 5760Z, 5760ZG

BATERIA Packard Bell EasyNote LS11 AS10D75 7800mAh PID06862

- TravelMate 6495, 6495G, 6495T, 6495TG
- TravelMate 6595, 6595G, 6595T, 6595TG
- TravelMate 7340, 7340G
- TravelMate 7740, 7740-352G32Mn, 7740-353G25Mnss, 7740-434G32Mnss, 7740G, 7740G-434G50Mnss, 7740ZG-P604G50Mnss, 7740Z-P604G32Mnss, 7740ZG
 - TravelMate 7750, 7750G, 7750Z, 7750ZG
 - TravelMate 8472, 8472 HF, 8472G, 8472G HF, 8472T, 8472T HF, 8472TG, 8472TG HF, 8472Z, 8472ZG
 - TravelMate 8473, 8473G, 8473T, 8473TG
 - TravelMate 8572, 8572G, 8572T, 8572T HF, 8572TG, 8572Z, 8572ZG
 - TravelMate 8573, 8573G
 - TravelMate TM5740, TM5740-X322, TM5740-X322D, TM5740-X322DF, TM5740-X322DHF, TM5740-X322DOF, TM5740-X322DPF, TM5740-X322F, TM5740-X322HBF, TM5740-X322OF, TM5740-X322PF, TM5740-X522, TM5740-X522D, TM5740-X522DF, TM5740-X522DHF, TM5740-X522DOF, TM5740-X522DPF, TM5740-X522F, TM5740-X522HBF, TM5740-X522OF, TM5740-X522PF, TM5742, TM5742-X732, TM5742-X732D, TM5742-X732DF, TM5742-X732DHF, TM5742-X732DOF, TM5742-X732DPF, TM5742-X732F, TM5742-X732HBF, TM5742-X732OF, TM5742-X732PF, TM5742-X742, TM5742-X742D, TM5742-X742DF, TM5742-X742DHF, TM5742-X742DOF, TM5742-X742DPF, TM5742-X742F, TM5742-X742HBF, TM5742-X742OF, TM5742-X742PF
 - TravelMate P Series: P TMP243-M, P TMP243-MG, P TMP253-E, P TMP253-M, P TMP253-MG

eMachines

- D400 Series: D440, D442, D443
- D500 Series: D528, D529
- D600 Series: D640, D640G, D642, D644, D644G
- D700 Series: D728, D729, D729Z, D730, D730G, D730Z, D730ZG, D732, D732G, D732Z, D732ZG
- E400 Series: E440, E442, E443
- E500 Series: E529
- E600 Series: E640, E640G, E642, E642G
- E700 Series: E729, E729Z, E732, E732G, E732Z, E732ZG
- G600 Series: G640, G640G
- G700 Series: G730, G730G, G730Z, G730ZG

Gateway

- NS411,
- NV Series: NV47H, NV49C13C, NV50A, NV51B, NV51M, NV52L, NV53A, NV53A11u, NV55C, NV55S, NV56R, NV57H, NV59C, NV73A, NS511, NV49xx, NV53, NV55C, NV79, NV49C, NV50A, NV53A, NV59C, NV73A, NV75S, NV76R, NV77H, NV79C

BATERIA Packard Bell EasyNote LS11 AS10D75 7800mAh PID06862

Packard Bell

- EasyNote LM81 LM82, LM83, LM85, LM86 LM87, LM94, LM98
- EasyNote NM85 Series: NM85-JN-030GE
NM85-GN-011UK NM85-GN-015UK
- EasyNote NM86 Series: NM86-GN-010 NM86-JN-108FR
- EasyNote NM87 NM87-JN-030GE NM87-GU-015UK
- EasyNote NM88 Series
- EasyNote NM89 Series
- EasyNote NM98 Series
- EasyNote LS11 Series:
 - EasyNote LS11HR Series: LS11-HR-050GE
LS11-HR-005 LS11-HR-006 LS11-HR-735CH
LS11-HR-821RU LS11-HR-233GE LS11-HR-010BE
LS11-HR-125GE LS11-HR-022IT LS11-HR-260
LS11-HR-231 LS11-HR-520RU LS11-HR-310
LS11-HR-353CZ LS11-HR-510RU LS11-HR-230
LS11-HR-104NCD LS11-HR-161GE LS11-HR-310RU
LS11-HR-104N LS11-HR-090GE
 - EasyNote LS11SB Series:
 - EasyNote LS13-HR Series: LS13-HR-195GE
LS13-HR-664CZ LS13-HR-664C LS13-HR-104GE
 - EasyNote NS11-HR Series: NS11-HR-033UK
NS11-HR-002FR NS11-HR-001CL NS11-HR-346CZ
NS11-HR-001NC NS11-HR-008 NS11-HR-001
 - EasyNote NS44-HR Series:
NS44-HR-033UK NS44-HR-001IT
 - EasyNote NS85 Series:
 - EasyNote TE11HC Series:
 - EasyNote TK11 Series: TK11BZ
 - EasyNote TK13 Series:
 - EasyNote TK36 Series: TK36-AV-115
 - EasyNote TK37 Series: (PEW92) TK37-AV-010UK
TK37-T354G25Mn
 - EasyNote TK81 Series: TK81-SB-001GE
 - EasyNote TK83 Series: TK83-RB-005GE
TK83-RB-020UK
 - EasyNote TK85 Series: TK85-GN-008GE
TK85-JN0-44FR
 - EasyNote TK87 Series: (PEW91) TK87-GU-210
 - EasyNote TM01, TM80 , TM81, TM82, TM83 (NEW95),
TM85, TM86, TM87, TM89 (NEW90), TM94
 - EasyNote TS11-HR Series: TS11-HR-100UK
TS11-HR-040UK TS11-HR-010GR TS11-HR-122GE
TS11-HR-036 TS11-HR-158GE TS11-HR-900NC
TS11-HR-002FR TS11-HR-514CH TS11-HR-320RU
TS11-HR-011FR TS11-HR-510 TS11-HR-232SP
TS11-HR-241SP TS11-HR-668CZ TS11-HR-011
TS11-HR-002NCD
 - EasyNote TS11SB Series:
 - EasyNote TS13-HR Series: TS13-HR-050UK

**BATERIA Packard Bell EasyNote LS11 AS10D75 7800mAh
PID06862**

TS13-HR-035 TS13-HR-035UK TS13 HR-037UK
TS13-HR-030UK TS13-HR-510RU TS13-HR-343CZ
TS13-HR-232 TS13-HR-322CZ TS13-HR-320RU
TS13-HR-032UK TS13-HR-004 TS13-HR-232SP
TS13-HR-645CZ TS13-HR-040UK

- EasyNote TS44-HR Series: TS44-HR-035UK
TS44-HR-037UK TS44-HR-015GE TS44-HR-260SP
TS44-HR-260PT TS44-HR-050FR TS44-HR-013NC
TS44-HR-244 TS44-HR-080 TS44-HR-320RU
TS44-HR-243SP TS44-HR-463CZ TS44-HR-080FR
TS44-HR-510RU TS44-HR-245SP TS44-HR-244SP
TS44-HR-021GE

- EasyNote TSX66 series:

Volts: 10.8V(11.1V)
mAh: 6600mAh
Tipo: Compatível
Dimensões: 271.3*53.2*42mm

Cel.: Li-Ion 9 Cel.
Cor: Preto
Garantia: 1 Ano

Peso: 460g

(não é uma lista completa).
Se não encontra o que procura ou tem dúvidas,
contacte-nos.

Preço: €64,07IVA Incluído (€52,09 Sem IVA)